

Common Questions about the Ultimate 1000 Lift™

Q: Why do I need the Ultimate 1000 Lift™ when I've always been lifting bodies by hand?

SAFETY! The NIOSH safety standards state a safe max lift by an adult male is 51 lbs. For females it is 46 lbs. If you or your employee injures their back - you have a bad back for the rest of your life not to mention the lost work and costs associated with doctors and/or surgery. How much is your healthy back worth?

Q: What is the Load Capacity of the Ultimate 1000 Lift™ ?

The Ultimate 1000 Lift™ lifts 1000 pounds. It was never designed to lift less.

Q: Who Installs the Ultimate 1000 Lift™?

Our certified installers or we can work with your contractor. It's easy.

Q: Do I have to have a track system to have the Ultimate 1000 Lift™?

No - You can mount it stationary and move your tables and caskets underneath it.

Q: How do I know what track system I need?

Our company will study your room and work flow and design a customized system so you ONLY get what you need.

Q: How is the lift made?

Built to run all day, every day, it is all made by hand in the US with only top quality parts.

Q: How long will my lift last?

There are Ultimate 1000 Lifts™ out there that are 60 years old! You can expect yours to run at least 30 years with little or no maintenance.

Q: What are the ceiling/building requirements to operate a lift?

It's recommended that your ceiling can handle around 1500 lbs. The lift weighs 200 lbs. and plugs into a regular 3 pronged outlet.

Q: How much head room does the lift take?

A stationary lift has an 8 inch drop from ceiling. A lift with track has a 17 inch drop from ceiling where the lift is parked.

Q: What is the warranty on the Ultimate 1000 Lift™?

6 months' parts and labor. 1 year parts. 10 years base of the machine.

Q: Where are the Ultimate 1000 Lifts™ installed?

Every state in the United States, as well as Germany, Mexico, Canada, Australia, Argentina, Japan, Italy, Ireland, Bermuda, and the Virgin Islands. Ask us for a reference in your local area.

Preguntas Y Respuestas de la maquina Ultimate 1000 Lift™

P#1: ¿Por qué es necesario tener la Ultimate 1000 Lift™, cuando yo siempre he recogido cuerpos a mano?

!Seguridad! El NIOSH las normas de seguridad del Estado dicen que el seguro máximo ascensor por un hombre adulto es 51 libras... Para las mujeres es 46 libras... Qué pasa si usted o su empleado causa daño a su espalda? Tiene una mala espalda por el resto de su vida por no mencionar la pérdida de trabajo y los costos asociados con los médicos y / o cirugía ¿Cuánto valor de la salud de su espalda?

P#2: ¿Cuál es la capacidad de carga de la maquina Ultimate 1000 Lift™?

La máquina Ultimate 1000 Lift™ levanta 1000 libras. Nunca fue diseñada para levantar menos.

P#3: ¿Quien instala la maquina Ultimate 1000 Lift™?

Nuestros instaladores certificados o podemos trabajar con el contratista. Es fácil.

P#4: ¿Tengo que tener un sistema de seguimiento para tener la maquina Ultimate 1000 Lift™?

No - Puede montar inmóvil y puede mover las mesas y ataúdes debajo de ella.

P#5: ¿Cómo puedo saber qué sistema de seguimiento que necesito?

Nuestra empresa estudiará su habitación y flujo de trabajo y vamos a diseñar un sistema personalizado para que usted sólo consiga lo que necesita.

P#6: ¿Como es hecha la maquina Ultimate 1000 Lift™?

Es hecha en los EE.UU. a mano de solamente partes de alta calidad.

P#7: ¿Cuánto tiempo durará mi Ultimate 1000 Lift™?

! Hay máquinas que están por ahí de 60 años de edad!
Usted puede esperar que la de usted va correr por lo menos 30 años, con poco o ningún mantenimiento.

P#8: ¿Cuáles son los requisitos de techo o de construcción para la operación de una máquina?

Se recomienda que el límite máximo que puede sostener su techo sea 1500 libras. La maquina pesa 200 libras y se conecta a un conector regular de tres entradas.

P#9: ¿Cuánto espacio de cabeza toma la máquina?

Una máquina estacionaria tiene una caída de 8 pulgadas. Uno con una pista de 17 pulgadas tiene una caída de 14 pulgadas de el techo a donde está la máquina estacionada.

P#10: ¿Cuál es la garantía de la maquina Ultimate 1000 Lift™?

Piezas y mano de 6 meses. 1 año en piezas . 10 años base de la máquina .

P#11: ¿Dónde están las máquinas instaladas?

Cada estado en los EE.UU., así como Alemania, México, Canadá, Australia, Argentina, Japón, Italia, Irlanda, Bermudas y las Islas Vírgenes. Pídanos por una referencia en su área local.