

Instructions for Installing the **THE ULTIMATE 1000 LIFT™** to the Ceiling Less Gantry System using Beam Clips

Please use the following instructions to secure your Ultimate 1000 Lift system to your Ceiling Less Gantry system.

Please follow the instructions carefully; if you have any questions about the steps, please call Mortuary Lift Company to get clarification before you begin this process.

Attaching the Ultimate 1000 Lift to the Ceiling Less Gantry System:

1. Balance the Green Strut perpendicular on top of the I-Beam.
2. Place the Machine under the I-Beam, plug the Ultimate 1000 Lift into an outlet.
3. Run the lifting straps out of the machine by depressing the "DOWN" button.
 - a. When the straps are long enough to reach the I-Beam, STOP.
4. Carefully flip the machine over and then fasten all four corner strap hooks onto the end holes of the green strut channel. (which is balanced on the I-Beam)
 - a. Press the "UP" button and begin to raise the machine upwards toward the I-Beam.
5. Attach the Machine to I-Beam using the (4) Beam clips.



Tollfree:800-628-8809

Phone:(319)364-4910

Fax:(319)364-4930

www.MortuaryLift.com

6. Tighten securely using, washers, bolts and lock nuts.
7. Un-hook lifting straps from green strut.

Attaching the Festoon Clamp to the I-Beam:

1. To secure your power cord to the end of your I-Beam, use the provided Festoon Clamp (shown in picture).
2. Make sure to tighten the clamp bolts until the lock washer is flat.



If you have any questions, or need further clarification on any steps please give us a call.

Thank You!

Tollfree:800-628-8809
Phone:(319)364-4910
Fax:(319)364-4930
www.MortuaryLift.com